

blu**rams**

Dome Lite 2-A31




Multilingual Manual & Guide


## Packing list



1 × Camera



1 × USB cable &  
Power adapter



1 × Screw  
accessory pack





1 × Plotting sheet



1 × Manual


## Get to know your camera





## 1. Plug in your camera

Plug the power adapter into a power outlet with USB cable connected. Please use the items included in the original package for optimal performance.



## 2. Download blurams App

Download the App by searching "blurams" in the App Store or Google Play. Alternatively, you can open a QR scanner App and scan the blurams App QR code below to install the App.




blurams App QR code



### 3. Add your camera into App

Enter into the blurams App, sign up for a free blurams account and log in. Go to the home page and Click the "+" icon on the top right corner, select your camera. Please follow the instruction on the App interface to add your camera.



## 4. Use of access to the cameras via a web interface

After you have installed the camera on your mobile phone and created an account with blurams there, you can also access the camera via a browser (Chrome, Firefox, Edge).

Please enter the following address in the address line:

<https://client.blurams.com/login>

Enter your registered email address, password and a verification code.

Click on your camera and the live image will appear. At the top right you will find a gear symbol. If you click on it you can change the settings of the camera and see the recordings made.

### FAQs

If you encounter any troubles in product information, product installation and use, please refer to the "Mine > Help And Feedback" in blurams app or email at [support@blurams.com](mailto:support@blurams.com).





## Give us your feedback

blurams strive for a high-quality product and user experience, we're eager to hear your feedback or suggestions. Send your feedback through the App or email at support@blurams.com.

### Note:

1. Do not use the camera in the environment at too high or too low temperature, never expose the camera under strong sunshine or too wet environment. The suitable temperature for the product and accessories is  $-10^{\circ}\text{C}$  to  $50^{\circ}\text{C}$ .
2. The charger type is A806A-050100U-EU1, XED-CE050100CU, TEKA-UCA10EU and output voltage/current is DC 5V/1A. The plug considered as disconnect device of adapter. If you use a third-party charger, the recommended output voltage/current of the adaptor is DC 5V/1A, and the adapter shall be CE approval type.
3. RF exposure information: The Maximum Permissible Exposure (MPE) level has been calculated based on a distance of  $d=20\text{cm}$  between the device and the human body. To maintain compliance with RF exposure requirement, use product that maintain a 20cm distance between the device and human body.
4. Operating Frequency Range: 2412 MHz 2472 MHz  
Max Output Power: 20dBm
5. This product can be used across EU member states.



Points de collecte sur [www.quefairedemesdechets.fr](http://www.quefairedemesdechets.fr)  
Privilégiez la réparation ou le don de votre appareil !

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

FCC ID: 2ASAQ-A31

## Congratulations!

Your camera is ready to use. Thank you for choosing blurams.



blurams Facebook



blurams Instagram

[support@blurams.com](mailto:support@blurams.com)

[www.blurams.com](http://www.blurams.com)